

Akai Remote Adapter Instructions

RC-17 Wireless Remote Adapter

This remote adapter required an external AC power adapter. For customers in North America an AC adapter is provided. Customers outside of North America will need to provide their own adapter. The adapter should put out between 6 and 12 Volts DC. The connector should be a standard 2.1mm x 5.5mm barrel connector with center positive. Current rating does not matter.

Installation: Turn off the tape deck. Plug the remote adapter into the remote connector on the back of the tape deck. Plug the AC adapter into the back of the remote adapter. The light on the front of the remote adapter should be on. Now power to the tape deck can be turned back on.

The remote adapter can control up to 6 functions of the deck: Play, Stop, F.F., Rewind, Record and Reverse Play. The functions map to the matching buttons on the remote control except Reverse Play is controlled by the #1 button on the keypad.

On the DirecTV remote the REC button must be double pressed to activate. For Record + Play, double press REC and then within ½ second of releasing REC press Play.

The remote adapter can be used with any universal remote programmed for the proper Sony VCR code. To select between them there are jumpers inside the unit. Remove the two screws on the bottom of the unit and remove the top cover. Located near the front window is a set of jumpers. The first two jumpers configure what type of Sony VCR codes the unit will respond to. See the table below for a list of jumper settings.

JMP1	JMP2	Device Code	DirecTV
JMP	JMP	Beta VCR	20033
JMP	OPEN	8mm VCR	20034
OPEN	JMP	VHS VCR	20032
OPEN	OPEN	LDP	----

Configuring the DirecTV Remote: To program the DirecTV remote first slide the switch at the top to AV1 or AV2. Press and hold the MUTE and SELECT buttons until the green light at the top blinks twice then release. Using the number keypad enter the 5 digit device code from the table above. If done correctly the green light will blink twice after the last digit is entered. The full manual for the DirecTV can be found here:

www.revoxremotes.com/Remotes/DirecTV.htm

www.R2R-Remotes.com

